





# CONVECTION

TRANSFER OF HEAT BY THE MOVEMENT OF HOT AR.

BUILDINGS DOWNWIND OF A FIRE CAN BE DAMAGED FROM CONVECTIVE HEAT 20 METRES AWAY.

# RADIATION


HEAT THAT TRAVELS OUTWARDS IN STRAIGHT LINES.

RADIATED HEAT CAN DAMAGE BUILDINGS 10 METRES AWAY.









This is a user friendly guide to CAN/CSA S504-19 -Fire resilient planning for northern communities. This guide is for communities located in or near the forest. It looks at how to be more fire resilient.

Communities, businesses, and individuals can take action and make a difference. They can reduce the risk of wildfire damage and help firefighters protect their property.



#### Understand the nature of fires

Fires spread faster in hot and windy conditions, when moving uphill, and in dense, evergreen forests.

Surface fuels are anything that burns on or near to the ground. For example, plants, leaves, twigs, dry grasses, stumps, needles, etc.

Ladder fuels allow fire to move from the ground into the trees. For example, tall shrubs, small trees, tree lichens, bark flakes, etc.

Embers are pieces of smouldering or flaming material that can travel a long way from a fire and start a new one. They can travel up to 500m with a strong wind.



#### Adapt buildings and the land around them to reduce the risk of wildfire

It is critical for northerners to plan and design fire resilient buildings and communities, as most of the north has limited firefighting resources and capacity.

The focus is on fuel: have less fuel available and use construction materials that don't burn well.

#### CONSIDER FIRE RESILIENCY FOR:

- \* Building materials
- \* Building location
- \* Landscaping
- \* Community planning

## SIDING

ROOFS

is not fire safe.

sticks, and other debris.

The best siding materials are metal and fire resilient

BUILDING MATERIALS

Roofing, siding, ventilation

The roof is the most important part of a building to

make fire safe. Embers from a fire or sparks from a

chimney can land on the roof and start a fire if the roof

Recommended roofing materials are concrete, metal, or

Regularly clear roof and eaves of dead leaves, needles,

fiberglass asphalt shingles with felt underlay.

#### VENTILATION

Smoke can travel through a building and cause a lot of damage, even if a building does not catch fire. Open vents can also carry embers between floors and rooms. Use fire resistant materials and design, and avoid open

# DECKS, SHEDS, FIREPITS

### Fire safety quidelines

Store all fuel (firewood, pellets, propane, etc) at least 10m away from a building.

Surround a firepit with at least 3m of non-burning material: e.g. bare soil, rock, concrete. Limit flying embers with a metal mesh screen over the firepit.

Clear burnable things away from under decks and balconies and for 1.5m around them.

Put a fire-safe mesh screen around the underside of decks and balconies

In a garage or shed, store burnable things away from any heat source.

Store no more than 50L of burnable liquids (gas, paint, alcohol, etc) in a garage or shed attached to a home.

PLANNING FIRE DIM



# (867) 873-6019 WWW.ECOLOGYNORTH.CA

Ecology North is a charitable organization, founded in 1971 to support sound environmental decision-making on an individual, community, and regional level.

Contact us or visit our website for information and other quides in this series.

Poster on the inside

Printed on recycled paper 2021

# LOCATION & LANDSCAPING

\* Higher temperatures

\* Treeline moving north

\* Stronger winds

\* More lightning

\* Dryer conditions - less rain and snow

\* More dead trees due to invasive species

These factors increase the risk of fire by adding fuel

sources and making it easier for fire to spread.

#### Clear away brush and flammable materials from around buildings

The most at-risk buildings are those built next to or in the bush. The forested area up to 100m out from a building should be looked at for fire safety.

For a fire resilient landscape, use these guidelines. Changes within 10m of a building have the most impact to reduce risk of wildfire.

#### 0 - 1.5M OUT FROM A BUILDING

\* Remove all fuels from the area

#### 1.5 - 100M OUT FROM A BUILDING

- \* Remove surface and ladder fuels
- \* Plant fire-resistant plants, like willow and birch
- \* Leave lots of space around evergreen trees
- \* Reduce the amount of dried needles and leaves on the ground



# PREVENTION IS KEY

#### Prepare for and respond to fire

#### CREATE A FIRE RESILIENCY PLAN

- \* Build a planning team
- \* Gather information to assess the risk
- \* Set goals to reduce the risk
- \* Share the plan and educate others \* Outline options to respond to wildfires
- \* Offer training for fighting wild and urban fires
- \* Update and review the plan every year

#### FIRE SUPPRESSION

Sprinkler systems prevent the spread of fire by wetting and cooling material, making it less flammable. Sprinklers are not usually effective at putting out fires.

Foam fire suppressants are effective at preventing fire spread and can be set up to spray automatically.

Use a firebreak — a wide strip of land with little vegetation (like a river or a road), meaning less fuel for a fire. It can stop a fire or limit the spread.



# PUTTING OUT FIRES


Know where the nearest source of water is, and how to access it

#### COMMON WATER SOURCES

- \* Fire hydrant or utilidoor
- \* Nearby water body
- \* Water truck

#### OTHER WATER SOURCES

A dry hydrant is a pipe that goes into the bottom of a nearby lake or river. If the bottom stays unfrozen in



A wall hydrant is a valve that brings water from inside a building to outside. A building with a wall hydrant and a large water tank could be use in an emergency.



# SCC S CCN

The Standards Council of Canada funded this guide as part of the Northern Infrastructure Standardization Initiative, with input from the Northern Advisory Committee (NAC).



With the permission of Canadian Standards Association, (operating as "CSA Group"), 178 Rexdale Blvd., Toronto, ON, M9W 1R3, material is reproduced from CSA Group's standards CAN/CSA S504-19 - Fire resilient planning for northern communities. This material is not the complete and official position of CSA Group on the referenced subject, which is represented solely by the Standard in its entirety. While use of the material has been authorized, CSA Group is not responsible for the manner in which the data is presented, nor for any representations and interpretations. No further reproduction is permitted. For more information or to purchase standards from CSA Group, please visit store. csagroup.org or call 1-800-463-6727.





